

FIG. 1




FIG. 2




FIG. 3




FIG. 4




FIG. 5




FIG. 6




FIG. 7




FIG. 8




FIG. 9




FIG. 12




FIG. 13




FIG. 10




FIG. 11




FIG. 12(a)




FIG. 12(b)




FIG. 13(a)




FIG. 13(b)

Security Manager

1(3)



Receiving terminal

Security Manager receives an invite. The security parameters are checked and new invite is requested.




FIG. 14(a)





FIG. 14(b)

FIG. 14(c)